



Sanding and surface prepare

Primer and chalk as a filler

To achieve an easily sanded high finish indoors on a painted surface, mix chalk with Primer to the consistency of a thick, paintable primer.



The primer can be sanded wet or dry.

- Apply with a brush.
- Leave to dry for approximately 30 minutes. Hot air can reduce the drying time to a few minutes.
- The primer can be sanded wet or dry and hardens all the way through without troublesome cracks due to shrinking.
- The primer can be used on indoor timber and walls.

Linseed Oil filler

To obtain a smooth linseed oil filler you can mix Linus Wallpaint with ground pumice to the desired consistency. The drying time is approximately 24 hours and it can be overpainted with Linseed Oil Paint or Linus Wallpaint.